



SOLENOID VALVES

FT3 - NG6 SOLENOID VALVES

Part No	Description
FT3-ES-2LL	Single Solenoid [P to A; B & T Blocked]
FT3-ES-1ML	Single Solenoid [Closed Centre]
FT3-ES-4ML	Single Solenoid [A+B Blocked; P to T "Tandem" Spool]
FT3-ES-0C	Double Solenoid [Open Centre "H" Spool]
FT3-12V	12 Volt DC Coil
FT3-24V	24 Volt DC Coil
FT3-115V	110 Volt AC Coil
FT3-230V	230 Volt AC Coil



FT3 - NG6 STACKABLE VALVES

Part No	Description
FT3-CP-A	Pilot Check Valve on A [Flow blocked from A1 to A, Free on B]
FT3-CP-B	Pilot Check Valve on B [Flow blocked from B1 to B, Free on A]
FT3-CP-AB	Double Pilot Check on A & B [Flow blocked from A1 to A and B1 to B]
FT3-FX-A	Throttle Check Valve on A [Flow is controlled from A to A1, free on B]
FT3-FX-B	Throttle Check Valve on B [Flow is controlled from B to B1, free on A]
FT3-FC-A	Throttle Check Valve on A [Flow is controlled from A1 to A, free on B]
FT3-FC-B	Throttle Check Valve on B [Flow is controlled from B1 to B, free on A]
FT3-FC-AB	Double Throttle Check Valve - [Flow is controlled from A1 to A, B1 to B]
FT3-RO-A	Pressure Reducing on 'A' - Drain to 'T'
FT3-RO-B	Pressure Reducing on 'B' - Drain to 'T'
FT3-RO-P	Pressure Reducing on 'P' - Drain to 'T'
FT3-MP-B	Pressure Relief Pilot Operated - Relief on 'B' and discharge to 'T'
FT3-MP-BA	Pressure Relief Pilot Operated - Relief on 'B' and 'A' - Discharge to 'T'
FT3-MP-AB	Pressure Relief Pilot Operated - Relief on 'B' and 'A' - Cross Discharge
FT3-CO-AB	One Way FCV - Flow Blocked from A1 to A - free on 'P' and 'T'
FT3-CO-B	One Way FCV - Flow Blocked from B1 to B - free on 'A', 'P' and 'T'
FT3-MO-P	One Way FCV - Pilot Operated - Relief on 'P' and discharge to 'T'
FT3-MP-P	Pressure Relief Pilot Operated - Relief on 'P' and discharge to 'T'



FT3 - NG6 MANIFOLD BLOCKS

Part No	Description
NG6-4MAN	Four Station

